

HY MICRO SPRAY TAPE

SAN-FU®



Installation Procedures



1. Punch Hole



2. Insert Peak



3. Screw Valve

★ Unfold the flat hose to spread the hole until it is fully opened.

★ Ensure the peak is inserted into the flat hose first.

★ Components of T-SV Valve:

1. Peak
2. Rubber Ring
3. Inner Tooth
4. Valve Body



Installation is successful after these 3 simple steps are done.
Note* PE Flat Hose is your best choice for flat ground irrigation.



SYSTEM COMPONENTS



+



SV Head Valve
+
Rubber Ring



1. DRILL



2. INSERT RUBBER RING



3. INSERT VALVE



ISO 9001:2008 SINCE 1976

- ❖ Valves connect with PVC pipes directly.
- ❖ No leakage.
- ❖ Simple installation, convenient operation.
- ❖ Suitable for different landscapes (e.g. hill).